
FLEXSON E300 - AFS

ACCESSORIES FOR SONOS

A	B	C	D	E	F	G	H	I	J	K	L
x4	x4	x8	x8	x8	x4	x4	x2	x2	x2	x2	2/3/4mm x1



- A — M6 20mm Button Head Hex Drive Screw / Bolt
- B — M5 18mm Button Head Hex Drive Screw / Bolt
- C — M6 Metal Leg
- D — M6 Nut
- E — M6 Plastic + Rubber Leg
- F — M5 16mm Countersunk Head Hex Drive Screw / Bolt
- G — M5 Flat Washer
- H — Safety / Security Cable
- I — Plastic Wall Plug (8mm Fixng Hole 40mm Long)
- J — 5mm x 50 Long Fully Threaded Pan Headed Pozi Drive Screw
- K — M4 10mm Flat Head Set Screw / Bolt
- L — 2 mm / 3mm / 4mm Hex Key Wrench

Exertis (UK) Ltd, St George House, Parkway, Harlow Business Park, Harlow, Essex, CM19 5QF, UK
Exertis Supply Chain Services Ltd., Sarseld Road, Raheem Bussiness Park, Limerick, V94 N72W


support@flexson.com


FLEXSON


ACCESSORIES FOR SONOS

E300 - AFS

EN Also required
FR Également requis
DE Ebenfalls benötigt
ES También se requiere







IMPORTANT SAFETY INSTRUCTIONS – Retain for future reference: ENGLISH

FOR SONOS ACCESSORIES

IMPORTANT SAFETY INSTRUCTIONS – Retain for future reference:

When using the Flexson mounting system, basic precautions should always be followed, including the following:

- Read the installation instructions carefully before installation and keep them in a safe place. If the product is passed on to a third party, also pass on the assembly instructions.

- Always unplug the SONOS speaker from the electrical outlet before installing it onto the Flexson mounting system.

WARNING - To reduce the risks of burns, fire, electrical shock, or injury to persons:

- Unplug the SONOS speaker from the outlet before putting it on, taking it off, or cleaning.

- Use this mounting system only for the installation of the intended SONOS speaker.

- Avoid contact with moisture/liquid



CAUTION: This mounting system is designed specifically for SONOS products. Using it with other products may lead to mount failure, causing injury or damage.

Additional Safety Guidelines:

- Follow only the instructions provided. Do not modify the product, and do not attempt to use or repair it if damaged.

- Ensure the floor can support **weight of the stand and speaker**. Contact a qualified professional if you have any concerns regarding the floor's suitability.

- **Use the included hardware** and tools as specified in the installation instructions to prevent product instability.

- If the floor stand has been supplied with a **safety cable**, this must be used to secure the stand and prevent accidental tipping.

- All Flexson floor stands are tested for tipping up to a **15-degree angle** to enhance stability. Do not exceed this limit or place additional objects on the stand or speaker.

- **Use only with SONOS speakers**. Exertis (UK) Ltd disclaims responsibility for misuse or improper installation with non-specified devices.

WARNING: Use correct replacement fixings for each FLEXSON wall mount or ceiling models.

Specific instructions and fixings for Installation

Floor Stands for All Models:

- Ensure secure and level placement of the stand on the floor.

- Tighten all screws and fittings as specified in the manual for the model being used.

ADDRESSES:

Manufactured by Exertis UK Ltd. Technology House Magnesium Way, Hapton, Burnley, England, BB12 7BF

EMAIL: customer.services@exertis.co.uk

ECONOMIC OPERATOR:

Exertis Supply Chain Services Limited, Unit 21 Fonthill Business Park, Clondalkin, Dublin 22, D22 FR82. Dublin, Ireland

EMAIL: SCSGPSR.UK@exertis.com